

NY Thermal Inc.
Tel: (506) 657-6000
Toll Free: 1-800-688-2575
Fax: 1-506-432-1135
Web: www.nythermal.com
Email: info@nythermal.com

84737
Burner Door Gasket, EPDM (Tx)
(GM10-25-125-02)

Applicable Boiler Models

- Tx51
- Tx81
- Tx101
- Tx151, Tx151C
- Tx200, Tx200C

Kit Contents

- 1 Burner Door Gasket

Tools Required

- 1/4" Nut Driver
- 10 mm wrench
- 5/16" nut driver
- Pipe wrench

Replacement Instructions

- 1) Turn off power and gas to the boiler.
- 2) Remove front cover then disconnect air-intake from the blower assembly.
- 3) Remove wiring harnesses and tubes from combustion blower gas valve, igniter, and flame probe.
- 4) Remove gas line from the gas valve.
- 5) Remove burner door, gas valve, and blower as an assembly then remove the old gasket.



WARNING

Crystalline Silica – Certain components confined in the combustion chamber may contain this potential carcinogen. Improper installation, adjustment, alteration, service or maintenance can cause property damage, serious injury (exposure to hazardous materials) or death.

- 6) Install the new gasket.



DANGER

Flue Gas Leakage – Failure to properly seal the burner door may result in leakage of flue gas which may lead to serious injury or death.

- 7) Re-assemble in the reverse order.