Revision Date: 2022-01-10



Tel: (506) 657-6000 Toll Free: 1-800-688-2575 Web: www.NTlboilers.com Email:Info@NTlBoilers.com

# 87268/8769

# **Sentry To Hydrosat Conversion**


Supplementary information if required (i.e. c/w gasket and washers)

### **Applicable Boiler Models**

• Caprice Boilers with Sentry 2000 or 2100 control

#### **Kit Contents**

- 84787-1, Hydro stat
- 84797 Hydrostat electro well
- Coil plate 3/4" NPT Or Coil 3/4" NPT
- 13501, Coil plate gasket
- 10647, 3/8" bolt x 8
- 10645, 3/8" nut x 8
- 86718, Remote mounting kit optional (sold separately)







Revision Date: 2022-01-10

# **Replacement Instructions**

- 1) Power down the boiler and drain the water.
- 2) Remove the DHW coil/ blank coil plate and replace it with the included plate.
- 3) Thread the new well into the plate using thread sealant.
- 4) Test fit the Hydrostat then attach the DHW supply and return if applicable.
- 5) Mount the Hydrostat directly to the well and use the Hydrostat instructions to wire and set the boiler.

